
nutplate
13/32"
10mm
edge of EFIS cutout
edge of EFIS lip
~1/2" glareshield
flange behind panel
switch guards
security starter switch
behind panel
ALT
WARN
ALT
5.0
PRESS TO RESET
STARTER
ENGAGED
EFIS PWR
BOTH ON
ALT/BAT
BOTH ON
LEFT MAG
ON
RIGHT MAG
ON
PUSH
START
B/U
ONLY
BAT
ONLY
OFF
OFF
OFF
OFF
PRIMER
primer
PULL ON
piano hinge
cabin heat
30 degree tilted main panel
vertical 1.5" subpanel