
TO STARTER



SWITCHES ARE SPRING LOADED IN THE UP POSITION (MOMENTARY)
MOVE BOTH SWITCHES UP TO START
RELEASE BOTH AFTER STARTING
SWITCHES WILL RETURN TO CENTER POSITION WHEN RELEASED