

Tyco has two coil wires, negative and positive.
How are they to be connected?

