

NOTES

1. The flasher will not operate unless both outputs are loaded with a lamp.
2. LED & HID lights require 75 ohm / 2W resistors be added from each flasher output to ground.
3. Alternate load resistor location is across the lamp.
4. A 30 second delay is required between lamp on and wig-wag.

