



GROUNDING NOTES:

- = ENGINE CRANKCASE GROUND
- = FIREWALL
- = INSTRUMENT PANEL GROUND BUS
- = AVIONICS GROUND BUS

- ALL GROUND LOCATIONS TIED BACK INTO BATTERIES AT G1
 - ALL EQUIPMENT HAVE SEPERATE GROUND WIRTS TO G2, G3, OR G5