


the aft end of the flap push/pull tube to the long end of
the bellcrank (F-8).

the length of the flap push/pull tube at the rod end (F-40)
the flap control handle. See drawing below.



FLAP ASSEMBLY

SPAKEMAN