



Note: All electrical equipment and conductive materials including the batteries are grounded to FT2. No electrical equipment is to be grounded directly to the airframe.

FT2 – Firewall passthrough  
 B-M – Main grounding  
 B-P – Main panel ground point  
 EFI – Engine ignition system

GlaStar N51DW		<b>1</b>
<b>Grounding System</b>	Modified	23 Oct 2020
	Created	17 Mar 2018
	Drawn By	Doug Windhorn